Savore Electric Pepper Grinder

Model #: OZG7 User Guide

Ozeri

Model #: OZG7 User Guide

Savore Electric Pepper Grinder, by Ozeri

Congratulations on your purchase of the Ozeri Savore Electric Pepper Grinder. Your Savore features a new sliding ceramic grind adjustor that makes it easy to choose from 3 preset grind levels. The Savore also features a battery-powered engine for effortless dispensing of pepper (or salt), an ultra-soft non-slip grip, and a convenient transparent storage container for your fresh peppercorn. Your Savore Electric Pepper Grinder consists of the following parts:

Outer Housing

Push Button Activation

Battery Housing
(6 AAA Batteries)

Storage Chamber

Grind Adjustor
(3 preset levels)

Copyright 2011, Ozeri

Ozeri

Model #: OZG7 User Guide

Savore Electric Pepper Grinder, by Ozeri

Accessing the Storage Chamber & Battery Housing:

1) While holding the Outer Housing still with one hand, twist the bottom Storage Chamber clockwise until it snaps into the unlock position. When unlocked, the white indicator arrow will align with the Unlock icon. **2)** Then separate the Storage Chamber from the Outer Housing. To access the Battery Housing, **3)** pinch the white tabs and remove the Battery Chamber from the Outer Housing. **4)** Insert 6 AAA batteries into the Battery Compartment, taking care to ensure the +/- battery polarities are correctly aligned. **5)** To reassemble, insert the Battery Chamber back into Outer Housing first. The Battery Chamber should snap into place via its white tabs. Then align the Outer Housing with the bottom Storage Chamber so that the white arrow is over the Unlock icon, and turn counterclockwise to snap back into the Lock position.

Hold Outer Housing firmly

Twist Bottom clockwise

Note: Please note the short distance between the locked and the unlocked icons on the Storage Chamber. Do not try to force the white arrow beyond these icons.

Copyright 2011, Ozeri

Ozeri

Model #: OZG7 User Guide

Savore Electric Pepper Grinder, by Ozeri

Adjusting the Grind on the Savore Electric Grinder:

To adjust the grind of your Ozeri Savore Grinder, slide the ceramic grind adjustor to one of the 3 preset positions -- Fine, Average, and Coarse, as indicated by the small, medium and large circular icons. The slider will snap into place.

Sliding Grind Adjustor

Fine **Average** **Coarse**

Care and Maintenance:

If your Savore Electric Grinder jams during use, it may be due to an excess of peppercorns in the grinder. Try shaking the unit to clear the peppercorns from the grinder. To clean this device, simply wipe with a clean damp cloth and allow it to dry naturally. Do not use abrasive cleaners and do not immerse in water or liquids. Do not use rock or wet sea salt with this device. This product is for indoor household use only. Keep this unit away from dust and oil. This unit is not a toy. Keep away from children.

- When adding peppercorns, be careful not to overfill the chamber.
- When using salt, do not use stone salt or wet sea salt.
- Store in an upright position to avoid rolling or accidently activating the push-button.
- When the Grinder begins to slow down, replace with batteries with 6 new AAA batteries.
- Remove the batteries if the Grinder will not be used for an extended period of time.
- For household indoor use only. Do not operate in extreme temperatures.
- Do not attempt to operate this product if it has been dropped or becomes damaged in any way.
- Do not attempt to disassemble the parts of this product.
- Keep this unit away from dust, oil and moisture.
- This unit is not a toy. Keep away from children.

Copyright 2011, Ozeri

Ozeri

Model #: OZG7 User Guide

Savore Electric Pepper Grinder, by Ozeri

Ozeri Warranty:

Your Ozeri Savore Electric Grinder is warranted to the original owner for 1 year from the date of purchase against defects in material and workmanship under normal use and service. Should your Ozeri Savore Electric Grinder prove defective within 1 year from the date of purchase, return the defective part or unit, freight prepaid along with an explanation of the claim to Ozeri. Please pack carefully to avoid damages in transit. Under this warranty, Ozeri will repair or replace any parts found to be defective due to a manufacturer's defect. This warranty extends only to personal use and does not extend to any product that has been used for commercial use, rental use, or use which is not intended. There are no warranties other than that expressly set forth herein. This warranty is not transferable. Ozeri is not responsible in any way for damages, losses or inconveniences caused by equipment failure or by user negligence, abuse, or use not in accordance with the "User Guide" or any additional safety, use, or warnings included in the product materials. Further, Ozeri is not liable for incidental or consequential damages of any nature resulting from the use of this product and any liability shall not exceed the purchase price of the product. This Warranty gives you specific legal rights. You may also have other rights which vary from state to state.

THIS WARRANTY DOES NOT APPLY TO THE FOLLOWING:

Damage due to accident, misuse, abuse, alterations or vandalism.
Improper or inadequate maintenance.
Unauthorized modification or commercial use.
Damage in return transit.
Unsupervised use by children under 18 years of age.

Ozeri Customer Service:
Email: support@ozeri.com
Phone: 1-877-299-1296

Copyright 2011, Ozeri